






Details / How-To

1. Navigate to Orchestrated Advanced QC → Cleaning and Sanitation → CIP



2. Next, click the  button and select the tank you are cleaning, and enter the date of the clean. Now enter the brand that was in the tank and the CIP method that was used. Click  and your done.
Full should be used for a nuke & sani. CIP for just a partial. Checks are also provided for CO2 Purge and Pressures.

Version 4.7.1.0